



- NOTES:
1. A ROOT BARRIER IS NOT REQUIRED OVER FIRESTONE RUBBERGARD EPDM OR ULTRAPLY TPO. SEE SKYSCAPE DESIGN AND INSTALLATION GUIDE FOR FURTHER INFORMATION.

2. SKYSCAPE DRAINAGE PANEL INCLUDES FILTER FABRIC BONDED TO TOP SIDE, AND GEOTEXTILE BONDED TO UNDERSIDE AS A SINGLE ROLL.

SKYSCAPE EDGE FLASHING (SIZED TO MEDIA DEPTH)

SKYSCAPE FILTER FABRIC

SKYSCAPE DRAINAGE PANEL; HIGH DENSITY POLYPROYLENE BONDED TO FILTER FABRIC TOP AND NON-WOVEN GEOTEXTILE BASE